





Place the FLEDBAG on a firm surface. Lift the big bag by its loops using front loader or forklift forks and position above the FLEDBAG.

**CAUTION:** Always position the FLEDBAG off-center and avoid piercing the bag where the material is thicker.



Lower the big bag so that the FLEDBAG penetrates the big bag, then raise the big bag again. For safety reasons, the FLEDBAG Original must be inserted into the big bag at an offcenter position.



Pull the FLEDBAG down slightly to make it easier to open and close the valve.



By opening and closing the FLEDBAG you can simply meter the content of the big bag. The slide must be opened towards the body.

Manitoba: 3700B McGillivray Boulevard, Winnipeg, MB R4G 0B5 Ph: 204.924.8265 Saskatchewan: 110-3240 Idylwyld Drive N, Saskatoon, SK S7L 5Y7 Ph: 306.956.7788

Alberta: 26424-115th Avenue, Acheson, AB T7X 6H2 Ph: 780.960.0725