





Open the first knot on the big bag outlet and push the tensioning ring onto the protruding discharge hose.



Position the FLEDBAG Easy on the discharge hose from underneath.



Pull the tensioning ring down, and fasten the tensioning ring with the discharge hose on the FLEDBAG Easy. Do not attach the tensioning ring at the top edge, but along the neck of the FLEDBAG.



Open the second knot on the outlet so that the content can run into the FLEDBAG Easy. Open the slide to empty. The slide must be opened towards the body.



FLEDBAG®
ORIGINAL
+
FLEDBAG®
EASY

FLEDBAG® PROFI

**Manitoba:** 3700B McGillivray Boulevard, Winnipeg, MB R4G 0B5 Ph: 204.924.8265 **Saskatchewan:** 110-3240 Idylwyld Drive N, Saskatoon, SK S7L 5Y7 Ph: 306.956.7788

Alberta: 26424-115th Avenue, Acheson, AB T7X 6H2 Ph: 780.960.0725